

eTrex[®] 20x / 30x

THE MOST POPULAR HANDHELD GPS MADE EVEN BETTER

This updated eTrex[®] GPS handheld takes the well-known and widely-loved eTrex experience and enhances it with an all-new 2.2" high resolution sunlight readable display, more than double the internal memory and preloaded Garmin TopoActive Western Europe mapping.



KEY FEATURES

NEW Upgraded Display

Features a 2.2" 65K colour sunlight readable display offering increased resolution (240 x 320 pixels).

NEW Preloaded Garmin TopoActive Map

Preloaded with Garmin TopoActive Western Europe mapping, providing information that is useful for recreational activities like hiking and cycling, it's routable, and shows elevation changes.

NEW More Memory

Increased internal memory and microSD™ card slot lets you load a variety of additional optional maps, including TOPO maps, BlueChart® g2, City Navigator NT® and BirdsEye Satellite Imagery (subscription required).

Keep Your Fix

With its high-sensitivity, WAAS-enabled GPS receiver, HotFix® satellite prediction and GLONASS support, eTrex locates your position quickly and precisely and maintains its location even in heavy cover and deep valleys.

Built-In Sensors

eTrex 30x adds a built-in 3-axis tilt-compensated electronic compass and a barometric altimeter which tracks changes in air pressure to pinpoint your precise altitude, and can be used over time to plot changing weather.

Wireless Capabilities

Share waypoints, tracks, routes and geocaches wirelessly with other compatible devices – simply press "send" to transfer your information. It also connects wirelessly to compatible Garmin devices, including VIRB® and accessory sensors, including tempe™, foot pod and heart rate monitor. (eTrex 30x only).

Ruggedised For The Outdoors

eTrex is built to withstand the elements – with an ergonomic, rugged design that stands strong against dust, dirt, humidity and water¹.

Go Anywhere

With an array of compatible mounts, eTrex is designed for use on bicycles, boats, quads, as a handheld, or in your car.

Paperless Geocaching

Supports geocaching GPX files for downloading geocaches and details straight to your eTrex – no more manually entering co-ordinates or paper printouts.

Long-Lasting Battery Life


Uses 2 AA batteries (not included) – supplying up to 25 hours of use (NiMH or Lithium recommended).




Garmin TopoActive Western Europe



Garmin TopoActive Western Europe With Routing



User-Friendly Interface



Track More Satellites



Optional Birdseye Satellite Imagery

PRODUCT CONFIGURATION

	Item	UPC	RRP
eTrex 20x GPS, Western Europe	010-01508-05	753759143299	€199
eTrex 20x, USB cable, documentation			
eTrex 30x GPS, Western Europe	010-01508-14	753759143305	€249
eTrex 30x, USB cable, documentation			

Map Coverage:

Garmin TopoActive Western Europe covers 23 countries: Andorra, Austria, Belgium, Denmark, Finland, France, Germany, Iceland, Ireland, Italy, Liechtenstein, Luxembourg, Malta, Monaco, Netherlands, Norway, Portugal, San Marino, Spain, Sweden, Switzerland, United Kingdom, Vatican City.

CASE PACK INFORMATION

Gift Box Dimensions	3.4"D x 2.7"W x 5.4"H 8.7 x 6.9 x 13.7cm
Gift Box weight	9oz / 255g
Case Pack	32 pcs/carton
Master Carton Dimensions	15"D x 12"W x 12.4"H 38.1 x 30.5 x 31.5cm
Master Carton Weight	18lbs. / 8.2kg

PRODUCT COMPARISON

	eTrex 10	eTrex 20x	eTrex 30x
Colour Display		•	•
Preloaded Garmin TopoActive West Europe		•	•
Worldwide Basemap	•	•	•
High-Sensitivity WAAS-Enabled GPS Receiver with HotFix® and GLONASS Support	•	•	•
3.7GB Internal Memory		•	•
MicroSD™ Card Slot		•	•
USB Interface	•	•	•
Paperless Geocaching	•	•	•
IPX7 Water Rating ¹	•	•	•
Electronic Compass			•
Barometric Altimeter			•
Wireless Capabilities			•

PHYSICAL AND PERFORMANCE

Unit Dimensions	2.1" W x 4.0" H x 1.3" D 5.4 x 10.3 x 3.3cm
Display type	2.2" Transflective, 65K colour TFT
Display resolution	240 x 320 pixels
Weight	5oz /142g with batteries
Battery	Uses AA batteries (not included) Up to 25 hours battery life
Water Rating	IPX7 ¹
Interface	USB
High-Sensitivity Receiver	Yes
Interface	High-speed USB and NMEA 0183 compatible
Preloaded Mapping	Garmin TopoActive Western Europe
Built-In Memory	3.7GB
Accepts Data Cards	Yes - microSD card (not included)
Waypoints	2000
Routes	200
Track log	10,000 points, 200 saved tracks

COMPATIBLE ACCESSORY OVERVIEW



SKU: 010-11734-00

UPC: 753759980276

Carrying Case

Protect your GPS with this close-fitting, lightweight case. Includes belt clip.

RRP: €11.99



SKU: 010-11838-00

UPC: 753759989392

Vehicle Power Cable

Plug into any 12V cigarette lighter receptacle to power your Garmin device and conserve battery life.

RRP: €19.99



SKU: 010-11855-00

UPC: 753759990138

Backpack Tether

Attach your handheld to any backpack. Hooks securely onto pack straps or accessory loops.

RRP: €19.99

AC Adapter	010-10635-01	753759049911	€14.99	Use this AC adapter to charge your eTrex by plugging into a wall outlet. Use with your micro USB cable.
Outdoor Mount Bundle	010-11853-00	753759990114	€19.99	Safely mount, store and protect your GPS device. Kit includes a carrying case, an easy-to-install cycling mount, and a handy universal mount that can be clipped on to a backpack or belt.
Carabiner Clip	010-11022-20	753759098179	€10.99	Keep your device within reach while on the move. Your device fits securely into a mount that clips to your belt.
Swivel Belt Clip	010-11022-10	753759093662	€7.99	Keep your device within reach while on the move. Your device fits securely into a mount that clips to your belt and swivels.
Belt Clip	010-11734-20	753759980375	€8.99	Keep your device within reach while on the move. Snap your device securely into the durable mount and clamp it to your belt.
BirdsEye Retail Card	010-11543-00	753759104023	€25.00	Retail card offering a one-year BirdsEye Satellite Imagery subscription for your compatible Garmin device.
Bike Mount	010-11023-00	753759074654	€11.99	Simply snap your device into this mount, and you're ready to ride. The mount comes with 4 cable ties and fits up to a 1" (2.54 cm) diameter bar.
Marine Mount	010-11031-00	753759075880	€29.99	Secure your device to any flat surface with this adjustable mount. Screws not included.
USB Cable	010-10723-01	753759052973	€6.99	Get the most out of your device with our USB cable. Use the USB cable to power your device. Create routes and waypoints on your personal computer and transfer them to your device.
Rechargeable Battery Kit	010-11343-00	753759096625	€26.99	Charge 2 AA or 2 AAA nickel-metal hydride batteries using an AC outlet with this rechargeable kit. It includes 2 AA NiMH batteries and international adapter plugs for the US, UK, Europe and Australia.